


# Strong magnet tracker

## Product instruction manual



## (Strong magnet tracker)



Please read the instructions carefully before using this product. This product is only used to assist the company or personal vehicle management, anti-theft and other legal purposes, prohibited for detective, tracking and other illegal activities that violate others' privacy.

## I . Product introduction

**1.Name:** Strong magnet tracker

**2.Feature:** Position query, electronic fence, vibration alarm, track playback. (All functions are subject to the actual model)

**3.Use:** Car rental, financial risk control, logistics management and other industries

**4.Configuration list:**

Number	Name	Quantity	Unit
1	Strong magnet tracker	1	set
2	Instruction manual, warranty card, certificate of qualification	1	set
3	Packing box	1	suit

Note: The above is the standard configuration list of the whole set of products. Accessories outside the above standard range of need to pay extra.

**5.Matters needing attention:**

- (1) Do not immerse the product in water.
- (2) Please keep the product away from extreme environments such as fire, high temperature and heat.
- (3) The shape and color of the equipment shall prevail.
- (4) It is strictly prohibited to disassemble, repair and modify products without permission.

## II . Specification parameter

**1. Main specifications:**

	Main specification
Master chip	4G module
Frequency	4G
Voltage	3.4-4.2V DC
Battery	Polymer battery: 3000mAh
Antenna	GPS ceramics and FPC
Shell	Fireproof material
Main interface	Type-C
SIM card	Nano Push self-ejecting cassette

**2. Main functions:**

	Main function
Battery display	Support
Positioning	Support
Playback	Support
Electronic fence	Support
Alarm message	Support
Vibration alarm	Support
Short message	Support
AGPS	Support

## III . Installation method

**1.Procedure of use:**

- Open the card slot and insert the SIM card that supports GPRS Internet access.
- Press and hold the power button for 3 seconds to power on the device. When you see the indicator light on and the blue light blinking quickly and the green light blinking frequently, it indicates normal.
- Log in to the mobile APP or website to check the location.

**2.Light status (On the device) :**

(1) GPS signal light (Green)

Light	Status
Glowing	GSM no positioning
Flashing	GPRS normal communication/online

(2) Network light (Blue)

Light	Status
Glowing	No signal found or the SIM card is invalid
Flashing	Quick blink: The system is working properly Blinking slowly: The server is not connected or there is no GPRS network

(3) Charge light (Red)

Light	Status
Glowing	The device is being charged
Extinguish	Charge complete

## IV . Common problem


Common problems	Reasons	Solutions
<b>Weak signal</b>	Test at areas where there are high buildings or underground parking lots, where radio waves cannot be sent or received normally.	Move to good signal The regional location used
<b>Platform map shows incorrect location</b>	GPS no location	go to outdoor place where signal is good
	Inaccurate positioning	The GPS signal is weak in some areas, and the terminal will switch different positioning modes. The positioning difference is normal
<b>The device and platform are not connected</b>	Check whether the SIM card is normal	Contact your provider to check the status of your SIM card
	The SIM card is normal, but the terminal is offline	Please try to observe the status in the strong signal area

**Notes:**


- 1) The equipment should be placed in a place with good GPS signal;
- 2) The equipment should be placed in a place that is not easy to corrode (waterproof measures);
- 3) Do not place the device directly in a place where the temperature is too high, such as: heat dissipation Near a pipe or exhaust port;
- 4) Ensure that the host face up, and there is no metal above the GPS signal shielding;
- 5) Do not fix the device on the controller, to avoid excessive temperature, battery expansion and shell deformation;
- 6) The equipment can not be suspended in the air in the position of long-term vibration, can be fixed with cable tie or double-sided tape.

## V . Installation position

**Installation position: Car**



**Installation position: Motorcycle**



**Installation position: electromobile**

